

F355 Engine Removal Connection checklist

Hoses/tubes			disconnect	reconnect
1	Radiator feed hose	firewall middle		
2	Radiator return hose	firewall middle		
3	Heater feed hose	firewall middle		
4	Heater return hose	firewall middle		
5	Coolant de-gas hose	firewall middle		
6	Fuel vapour vent hose	LHS front corner		
7	Fuel feed LHS	LHS front corner		
8	Fuel return LHS	LHS front corner		
9	Fuel feed RHS	RHS front corner		
10	Fuel feed RHS	RHS front corner		
11	Secondary air rail (remove entire tube asy)	exhaust manifolds & RHS rear corner		
12	vacuum feed to reservoir	RHS rear corner		
13	Power steering feed	firewall LHS		
14	Power steering return	firewall LHS		
15	A/C feed	inside LHS wheel arch		
16	A/C return	inside LHS wheel arch		
17	Brake line LHS	LHS wheel arch		
18	Clutch line LHS	LHS wheel arch		
19	Brake line RHS	RHS wheel arch		
20	Oil feed to oil cooler	RHS wheel arch		
21	Oil return from oil cooler	RHS wheel arch		

Electrical				
22	Main starter and alternator cables (2 cables)	RHS middle		
23	Suspension actuator LHS	LHS wheel arch, upper		
24	Suspension actuator RHS	RHS wheel arch, upper		
25	ABS connection LHS	LHS wheel arch, upper		
26	ABS connection RHS	RHS wheel arch, upper		
27	Lambda connector LHS	LHS rear corner		
28	Lambda connector RHS	RHS rear corner		
29	Engine loom connectors LHS (2 plugs)	LHS rear corner		
30	Engine loom connectors RHS (2 plugs)	RHS rear corner		
31	ECU connector LHS	LHS rear corner		
32	ECU connector RHS	RHS rear corner		
33	Aux connector LHS	LHS rear corner		
34	Thermocouple connector LHS	LHS rear corner		
35	Thermocouple connector RHS	RHS rear corner		
36	Ign. Coil connector LHS	LHS middle		
37	Ign. Coil connector RHS	RHS middle		
38	Oil sensor connector	underneath oil tank		

Other				
39	Handbrake linkage	LHS wheel arch		
40	Gearshift rod	below vehicle, both ends		
41	Throttle cable	central, below water tank		

Additional model specific items				